

## F-SERIES ALL CABS FRONT FLOOR CROSSMEMBER INSTALLATION - SERVICE KIT INSTRUCTIONS

KIT		
Part Number	Description	Quantity
FL34-1510692-AD	Front Floor Crossmember All Cabs	1
SKFL34-1510692-AA	Instruction Sheet	1

KIT		
Part Number	Description	Quantity
FL34-15111C68-AG	Center Floor Reinforcement All Cabs	1
SKFL34-1510692-AA	Instruction Sheet	1

NOT INCLUDED IN KIT (PROCURE LOCALLY)		
Part Number	Description	Quantity
W708777-S900C	Blind Rivet	36
W702512-S900C	Blind Rivet	55
Motorcraft TA-1, 3M 8115 or Fusor 108B	Metal Panel Bonding Adhesive	1

KIT		
Part Number	Description	Quantity
FL34-1510024-AC	Torque Box Extension All Cabs - (RH)	1
SKFL34-1510692-AA	Instruction Sheet	1

KIT		
Part Number	Description	Quantity
FL34-1510025-AD	Torque Box Extension All Cabs - (LH)	1
SKFL34-1510692-AA	Instruction Sheet	1

NOT INCLUDED IN KIT (PROCURE LOCALLY)		
Part Number	Description	Quantity
W708777-S900C	Blind Rivet	36
W702512-S900C	Blind Rivet	55
Motorcraft TA-1, 3M 8115 or Fusor 108B	Metal Panel Bonding Adhesive	1

KIT		
Part Number	Description	Quantity
FL34-1510414-AC	Torque Box All Cabs - (RH)	1
SKFL34-1510692-AA	Instruction Sheet	1

KIT		
Part Number	Description	Quantity
FL34-1510415-AC	Torque Box All Cabs - (LH)	1
SKFL34-1510692-AA	Instruction Sheet	1

**SKFL34-1510692-AA**

**SHEET 1 OF 5**



<b>NOT INCLUDED IN KIT (PROCURE LOCALLY)</b>		
<b>Part Number</b>	<b>Description</b>	<b>Quantity</b>
W708777-S900C	Blind Rivet	36
W702512-S900C	Blind Rivet	55
Motorcraft TA-1, 3M 8115 or Fusor 108B	Metal Panel Bonding Adhesive	1

<b>KIT</b>		
<b>Part Number</b>	<b>Description</b>	<b>Quantity</b>
FL34-15000L06-AC	Body Mount Reinforcement All Cabs - (RH)	1
SKFL34-1510692-AA	Instruction Sheet	1

<b>KIT</b>		
<b>Part Number</b>	<b>Description</b>	<b>Quantity</b>
FL34-15000L07-AD	Body Mount Reinforcement All Cabs - (LH)	1
SKFL34-1510692-AA	Instruction Sheet	1

<b>NOT INCLUDED IN KIT (PROCURE LOCALLY)</b>		
<b>Part Number</b>	<b>Description</b>	<b>Quantity</b>
W708777-S900C	Blind Rivet	36
W702512-S900C	Blind Rivet	55
Motorcraft TA-1, 3M 8115 or Fusor 108B	Metal Panel Bonding Adhesive	1

<b>KIT</b>		
<b>Part Number</b>	<b>Description</b>	<b>Quantity</b>
FL34-1610418-AH	Sled Runner All Cabs - (RH)	1
SKFL34-1510692-AA	Instruction Sheet	1

<b>KIT</b>		
<b>Part Number</b>	<b>Description</b>	<b>Quantity</b>
FL34-1610419-AH	Sled Runner All Cabs - (LH)	1
SKFL34-1510692-AA	Instruction Sheet	1

<b>NOT INCLUDED IN KIT (PROCURE LOCALLY)</b>		
<b>Part Number</b>	<b>Description</b>	<b>Quantity</b>
W708777-S900C	Blind Rivet	36
W702512-S900C	Blind Rivet	55
Motorcraft TA-1, 3M 8115 or Fusor 108B	Metal Panel Bonding Adhesive	1

SKFL34-1510692-AA

SHEET 2 OF 5



**SERVICE GUIDELINES:**

- Aluminum repairs should be performed in an area protected from steel working areas, and tools used in aluminum repair should be quarantined from steel repair tools.
- Replacement Self-Piercing Rivets (SPRs) are the preferred replacement during repair for original SPR locations, where feasible. Blind rivets are the next preferred replacement for original SPRs. In some cases, solid rivets may also be used as a replacement for SPRs. The figures will explicitly call out which rivets are possible.
- Replacement SPRs are to be installed adjacent to original SPR location.

**NOTE: Do not install replacement SPR in original SPR hole.**

- Blind rivets may be installed in original SPR holes, after they are reamed out to 6.5mm. Be sure to grind all surfaces of the flange smooth prior to blind rivet installation in original SPR locations.
- Flow Drill Screws (FDS) are to be replaced by blind rivets only. The original location of the FDS is used, but reamed out to 6.5mm.
- Rivets may be removed by drilling, grinding, or SPR gun set up as a rivet removal tool.
- Using heat (not exceeding 425 °F) to loosen a rivet bonded panel should only be done when all panels in the joint will be replaced or separated and new adhesive applied.
- Flange preparation for adhesive is to grind to clean metal with 80-120 grit, clean, and then apply the adhesive, spreading it out with an acid brush, covering any exposed aluminum.
- Clecos are an excellent way to hold the panels into position when fitting and drilling rivet holes.



## THE FOLLOWING ARE COMMON BETWEEN ALL CAB STYLES

- **Black dots represent the location of the blind rivets (W702512-S900C).**
  - Four (4) rivets (two (2) per side) to dash and torque box.
  - Four (4) rivets (two (2) per side) between the sled runner and #2 crossmember.
  - Ten (10) rivets (five (5) per side) between torque box and torque box extension.
  - Eight (8) rivets (four (4) per side) between torque box and sled runner.
  - Eight (8) rivets (four (4) per side) between torque box extension and #1 crossmember.
  - Five (5) rivets between center floor reinforcement and #2 crossmember.
  - Ten (10) rivets (five (5) per side) between sled runner and #1 crossmember.
  - Four (4) rivets (two (2) per side) between sled runner and #1 crossmember, (**Crew Cab only**).
  - Two (2) rivets between center floor reinforcement and #1 crossmember.
- **Black squares represent the location of the blind rivets (W708777-S900C)**
  - Two (2) rivets (one (1) per side) between the tunnel and the dash and torque box.
  - Sixteen (16) rivets (eight (8) per side) between the side sill and #1 crossmember.
  - Six (6) rivets (three (3) per side) between the side sill and torque box.
  - Twelve (12) rivets (six (6) per side) between the side sill and torque box extension.




FIGURE 1

SKFL34-1510692-AA

SHEET 4 OF 5



CPR © 2014 FORD MOTOR COMPANY  
DEARBORN, MICHIGAN 48121  
10-14

F-SERIES ALL CABS FRONT FLOOR  
CROSSMEMBER INSTALLATION -  
SERVICE KIT INSTRUCTIONS

- (Refer to Figure 2) for location for adhesive material.

**NOTE:** The location of SPR and adhesive shown below are based on the original production drawings and should only be used as a guideline. (Refer to Figure 2).

BLACK WAVY LINES  
REPRESENT THE  
LOCATION OF THE  
ADHESIVE MATERIAL




FIGURE 2

